

1		2		3		4		5		6		7		8									
A	相 母 线 截 面		3-TMY-125x10												A								
	N 母 线 PE 母 线		TMY-80x8 TMY-80x8																				
	盘 编 号 / 盘 宽 * 深 * 高		AA26/800*1000*2200		AA24/800*1000*2200																		
	回 路 编 号 / 二 次 接 线 图 号		II段电容补偿柜		1/低压控制原理图7		2/低压控制原理图7		3/低压控制原理图7		4/低压控制原理图7		5/低压控制原理图7			6/低压控制原理图7		7/低压控制原理图7		8/低压控制原理图7		9/低压控制原理图7	
	抽 屉 单 元		8E		8E		8E		8E		8E		8E			8E		8E		8E		8E	
	塑壳断路器 / 双电源开关 / 刀熔开关		QSA-630/3P 630A		NSX100H TMD63 3P3D+OF+SD		NSX100H TMD16 3P3D+OF+SD		NSX100H TMD16 3P3D+OF+SD		NSX100H TMD16 3P3D+OF+SD		NSX100H TMD16 3P3D+OF+SD			NSX100H TMD16 3P3D+OF+SD		NSX100H TMD16 3P3D+OF+SD		NSX100H TMD16 3P3D+OF+SD		NSX100H TMD16 3P3D+OF+SD	
	接 触 器		控制器 Sinexcel JKF 24J-S 熔断器 15*NT00-160/125A 接触器 5*Sinexcel JC-60 电抗器 5*Sinexcel 60R 480-3L-7 电容器 10*Sinexcel 30C 480-3L 避雷器 3*FYS-0.22 多功能仪表 SPM33-T-E7-PS																				
	热继电器																						
	快速熔断器																						
	多功能仪表				SPM32-N-SR-PS		SPM32-N-SR-PS		SPM32-N-SR-PS		SPM32-N-SR-PS		SPM32-N-SR-PS			SPM32-N-SR-PS		SPM32-N-SR-PS		SPM32-N-SR-PS		SPM32-N-SR-PS	
C	变频器 + 输出电抗器																						
	电动机保护器 PMAC801A																						
	电 流 互 感 器 AKH-0.66 0.5S级 2.5VA		3*(600/1)		3*(60/1A)		3*(10/1A)		3*(15/1A)		3*(10/1A)		3*(10/1A)		3*(10/1A)		3*(10/1A)		3*(15/1A)		3*(10/1A)		
	浪涌保护器 + 后备保护器																						
	无线六点测温装置		DING-W																				
	漏电继电器 + 零序互感器				SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		SHYS-EG(T)R+ZCT-Φ45		
	垂直出线排				3*TMY-40*6																		
	出线零排				TMY-40*4																		
	设 备 容 量 (kW)				63		5		5		3.5		3.5		5		5		9		5		
	回 路 名 称				备 用		电动阀		电动阀		电动阀		电动阀		电动阀		电动阀		电动阀		电动阀		
回 路 编 号						MV150008B		MV150008A		MV150009B		MV150009A		MV150006B		MV150006A		MV1500002		MV1500003			
D																							
E																							
F																							